



HLS-250

250-Watt Halogen Illuminator Service Manual

6018 Bowdendale Avenue
Jacksonville, FL 32216

Customer Service: 904 737 7611 FAX 904 733 4832
Toll Free 877 677 2832

LIT116 CUDA
(English)

250 WATT HALOGEN SERVICE MANUAL

TABLE OF CONTENTS	Page
INTRODUCTION.....	3
TECHNICAL SUPPORT SERVICES.....	3
GENERAL THEORY OF OPERATION	4
FUSE HOLDER REPLACEMENT.....	5
SHUTTER REPLACEMENT.....	5
LAMP HOLDERE REPLACEMENT	6
TRANSFORMER REPLACEMENT	6
COOLING FAN REPLACEMENT.....	6
REPLACEMENT PARTS	8
Figure 1.	7

250 WATT HALOGEN SERVICE MANUAL

INTRODUCTION

This manual has been prepared to aid in the repair and maintenance of the 250-Watt Halogen Illuminators.

The procedures and instructions contained in this document are to be used by qualified technical personnel only. Some procedures may have live exposed circuitry and wiring which could be hazardous if contacted with. Use extreme caution when working on equipment that has power applied to it.

TECHNICAL SUPPORT SERVICES

In the event that you experience difficulty or need technical assistance, please contact our technical support staff at (877) 677-2832 or by fax at (904) 733-4832. Please have the following information ready when you call:

- Model number
- Serial number
- Detailed description of the problem

250 WATT HALOGEN SERVICE MANUAL

GENERAL THEORY OF OPERATION

The 250-watt halogen illuminator general operation is as follows. Please consult Figure 1 for wiring information.

A.C. POWER DISTRIBUTION

The 250-watt halogen illuminator is based around a selectable input transformer. Input line voltages of 115V ~ at 50/60 Hz and 230V~ at 50 Hz are applied at the power input model via a hospital grade power cord. Over-current protection is provided by two 3-amp fuses. A double-pole interlock switch located on the front right side of the lamp heat shield, provides operator safety.

INTENSITY CONTROL

A rotating stainless steel disc that is placed in front of the lamp controls intensity. The disc contains holes in varying sizes and patterns. Manual lamp intensity control is made via a front panel mounted knob.

COOLING SYSTEM

Cooling is provided by a 53FM, 115 VAC fan. Air is drawn through the sides of the unit, across the transformer and lamp, and exhausted through the rear mounted exhaust louver. Caution should still be used, as there are still potentially hazardous temperatures at the turret.

PARTS REPLACEMENT PROCEDURES

The following procedures are meant to aid the technician/engineer in replacing defective or damaged components. These procedures are meant to be used by qualified personnel only. Extreme caution should be used and all necessary safety precautions taken when working on this equipment.

250 WATT HALOGEN SERVICE MANUAL

FUSE HOLDER REPLACEMENT

1. Disconnect the illuminator from the power source.
2. Remove the 8 cover screws of the unit.
3. Remove top cover. Set aside.
4. Remove the defective circuit breaker and replace with the new one.
6. Replace the top cover.
7. Replace the 8 cover screws and secure.

SHUTTER REPLACEMENT

1. Disconnect the illuminator from the power source.
2. Remove the 8 cover screws in the sides of the unit.
3. Open lamp access door and remove from unit.
4. Remove the lamp and loosen the screws on the bottom of the lamp holder. Remove the standoffs and shield.
5. Remove the screw holding the shutter to the front panel.
6. Pull off the shutter assembly.
7. Replace the shutter assembly with the new one.
8. With the control turned fully clockwise, align the shutter in such a way that it does not cover the hole in the front panel. Replace the screw and tighten the screw until it holds the shutter in place and still allows for free movement of the shutter. **Do not over tighten the screw.**
9. Replace the shield and standoffs.
10. Replace the lamp holder and tighten screws, insert lamp and lamp wires and insert lamp drawer into unit.
11. Replace the 8 cover screws and secure.

250 WATT HALOGEN SERVICE MANUAL

LAMP HOLDER REPLACEMENT

CAUTION: Before performing this procedure, be sure the unit has cooled to room temperature.

1. Disconnect the illuminator from the power source.
2. Open lamp access door and remove from unit.
3. Remove the lamp.
4. Loosen screws that hold the lamp holder to the lamp door.
5. Replace lamp holder and fasten with the screws.

TRANSFORMER REPLACEMENT


1. Disconnect the illuminator from the power source.
2. Remove the 8 cover screws in the sides of the unit.
3. Remove the top cover from the unit. Set aside.
4. Disconnect the fan lead connector, the AC power input connectors, and the lamp output power wires from the power supply.
5. Set the unit on its side.
6. While holding the transformer with one hand, remove the 4 mounting screws from the bottom of the unit.
7. Place the new transformer in the unit so all 4 holes line up with the holes in the chassis. Secure with the 4 mounting screws from the bottom.
8. Place the unit back on its feet.
9. Reconnect the fan lead connector, the AC power input connectors, and the lamp output power wires to the power supply.
10. Replace the top cover.
11. Replace the 8 cover screws and secure.

COOLING FAN REPLACEMENT

1. Disconnect the illuminator from the power source.
2. Remove the 8 cover screws of the unit.
3. Disconnect the fan lead connector from the transformer.
4. Remove the fan mounting screws and nuts. This will free the fan louver also.
5. Replace the fan assembly with the airflow blowing out the back of the unit. The fan leads should be coming out of the fan at the tip and against the back panel.
6. Secure the fan mounting screws with the nuts.
7. Reconnect the fan lead connector to the transformer.
8. Replace the top cover.
9. Replace the 8 cover screws and secure.

250 WATT HALOGEN SERVICE MANUAL

Figure 1



CODE	DESCRIPTION	QTY
FS1/FS2	1.5 AMP FUSE	2
S1	LIMIT SWITCH	2
S2	ON/OFF SWITCH	1
S3	VOLTAGE SELECTOR SWITCH	1
T1	115-230 VOLT TRANSFORMER	1
L1	EJA LAMP	1
F1	FAN	1
DT1	THERMOSTAT DISC	1

250 WATT HALOGEN SERVICE MANUAL

REPLACEMENT PARTS

<u>DESCRIPTION</u>	<u>PART NUMBER</u>
Lamp holder	001116000
250-Watt Transformer	1101516
Fuse holder	0011132000
Cooling Fan	001110001

For parts not listed here, call our Technical Service Department listed at the front of the manual.